

ECG STM32

Jose David Alvarado Moreno
Procesamiento de señales.



AGENDA

Características del sistema.

Entrada

- Sensor análogo XD-58C.
- Filtro antialiasing.

STM32

- NUCLEO-H7A3ZI-Q
- ADC y UART
- Filtro FIR y Moving average

PC

- UART
- Visualización por matplotlib Python.



Entrada: Sensor de pulso cardiaco.


- Modelo: XD-58C
- Medición: Pulso cardíaco
- Voltaje de alimentación: 3.3V ~ 5V
- Corriente: 4 mA
- Longitud de Onda del led: 609 nm (nanómetros)

NUCLEO-H7A3ZI-Q

Frecuencia: 280MHz

ADC: 16 Bits

UART: 460800, 8 - bits.



NUCLEO-H7A3ZI-Q

ADC2 Mode and Configuration

Mode

☒ IN0

Configuration

Reset Configuration


☒ NVIC Settings ☒ DMA Settings ☒ GPIO Settings

☒ Parameter Settings ☒ User Constants

Configure the below parameters :

Search (Ctrl+F)

| | |
|---------------------------------|--|
| ADCs_Common_Settings | |
| Mode | Independent mode |
| ADC_Settings | |
| Clock Prescaler | Asynchronous clock mode divided by 1 |
| Resolution | ADC 16-bit resolution |
| Scan Conversion Mode | Disabled |
| Continuous Conversion Mode | Disabled |
| Discontinuous Conversion Mode | Disabled |
| End Of Conversion Selection | End of single conversion |
| Overrun behaviour | Overrun data preserved |
| Left Bit Shift | No bit shift |
| Conversion Data Management Mode | Regular Conversion data stored in DR register o... |
| Low Power Auto Wait | Disabled |
| ADC_Regular_ConversionMode | |
| Enable Regular Conversions | Enable |
| Enable Regular Oversampling | Disable |



NUCLEO-H7A3ZI-Q

USART3 Mode and Configuration

Mode

Mode

Configuration

Reset Configuration

☒ NVIC Settings ☒ DMA Settings ☒ GPIO Settings

☒ Parameter Settings ☒ User Constants

Configure the below parameters :

Basic Parameters


| | |
|-------------|---------------------------|
| Baud Rate | 460800 Bits/s |
| Word Length | 8 Bits (including Parity) |
| Parity | None |
| Stop Bits | 1 |

Advanced Parameters


| | |
|------------------|-----------------------------|
| Data Direction | Receive and Transmit |
| Over Sampling | 16 Samples |
| Single Sample | Disable |
| ClockPrescaler | 1 |
| Fifo Mode | Disable |
| Txfifo Threshold | 1 eighth full configuration |
| Rxfifo Threshold | 1 eighth full configuration |

Advanced Features

| | |
|-------------------------------|---------|
| Auto Baudrate | Disable |
| TX Pin Active Level Inversion | Disable |



Diseño del Filtro FIR (pyFDA)



Implementación del Moving average



```
int k = 20 ; // Tamaño de la ventana
for (int i=0; i < k; i++)
{
    adcm[0] = adcm[0] + adc[i];
}
adcm[0] = (int16_t) (adcm[0] / (k));
for (int i=1; i<(header.N-1) ; i++)
{
    adcm[i] = (int16_t) (adcm[i-1] + ((adc[i+k]-adc[i-1]) / (k)));
}
arm_conv_q15(adcm, header.N, h, h_LENGTH, y); // Filtro FIR
```



Tiempo de adquisición y transmisión.

Visualización

ECG STM32 NUCLEO-H7A3ZI



Visualización

ECG STM32 NUCLEO-H7A3ZI

